



Vikoflex® 7190 Epoxidized Linseed Oil Providing solutions for increasing performance and sustainability

Vikoflex[®] 7190 is an epoxidized linseed oil. It is recommended for PVC homopolymer and copolymer plasticization and stabilization in a host of rigid, semi-rigid, flexible extruded, calendered, and molded compounds. Vikoflex[®] 7190 is well suited for formulations requiring maximum oxirane content and efficient acid scavenging.

USAGE RECOMMENDATIONS

- Plasticization of PVC flexible and semi-rigid compounds.
- Acid acceptance in chlorinated hydrocarbons, phosphoric acid esters, and natural resins.
- Acid scavenging of lubricating oils and cutting oils.
- Plasticization of PVC and PVA emulsions.
- Acid acceptance in chlorinated hydrocarbons, phosphoric acid esters, and natural resins.

PHYSICAL PROPERTIES

% Oxirane Content	9.2%
Viscosity at 25°C (cps)	800
Specific Gravity	1.03
APHA Color	175
EEW	174
Moisture Content (%)	< 0.05
Acid Value (mg KOH/g)	0.2
Iodine Value	2.5



VIKOFLEX® EPOXY PLASTICIZERS

The Vikoflex[®] line of epoxy plasticizers and reactive diluents are derived from renewable resources. Applications include PVC plasticization, acid and mercaptan scavenging, specialty coatings, adhesives, urethanes, and PU flexible foam.

PACKAGING

Vikoflex[®] 7190 is available in 40 lb. pails, in 55-gallon (450 lb. net) drums, and 2,200 lb. totes.

GEOGRAPHIC AVAILABILITY

All Arkema Epoxide products are currently manufactured in the USA in Blooming Prairie, MN. Please contact us on our website or our customer service email listed below for more specific information on supply to specific geographic area of interest.

HEALTH, ENVIRONMENTAL AND SAFETY INFORMATION

- Before handling this material, read and understand the SDS (safety data sheet) for health, environmental and safety information.
- SDS are available on our website at www.arkemaepoxides.com or upon request at our customer service department.

FOR MORE INFORMATION

Please contact your local account manager or our headquarters:

Arkema Inc.

Oxygénés & Derivatives Customer Service 900 First Avenue King of Prussia, PA 19406-1308 USA Tel.: +1 (800) 346-5757 Fax: +1 610-205-7634 Email: arkema.usph-hydrogen-peroxides-cs@ arkema.com

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. See SDS for Health & Safety Considerations.

Arkema has implemented a Medical Policy regarding the use of Arkema products in Medical Device applications that are in contact with the body or circulating bodily fluids: (http://www.arkema.com/en/socialresponsibility/responsible-product-management/medical-device-policy/index.html). Arkema has designated Medical grades to be used for such Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications that are in contact with the body or circulating bodily fluids. In addition, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. The Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices.

It is the sole responsibility of the manufacturer of the medical device to determine the suitability (including biocompatibility) of all raw materials, products and components, including any medical grade Arkema products, in order to ensure that the final end-use product is safe for its end use; performs or functions as intended; and complies with all applicable legal and regulatory requirements (FDA or other national drug agencies). It is the sole responsibility of the manufacturer of the medical device to conduct all necessary tests and inspections and to evaluate the medical device under actual end-use requirements and to adequately advise and warn purchasers, users, and/or learned intermediaries (such as physicians) of pertinent risks and fulfill any postmarket surveillance obligations. Any decision regarding the appropriateness of a particular Arkema material in a particular medical device should be based on the judgment of the manufacturer, seller, the competent authority, and the treating physician.

Vikoflex® is a registered trademark of Arkema.

© 2019 Arkema Inc. All rights reserved.



For more information, please contact your local account manager or our headquarters:

ARKEMA

Oxygénés & Derivatives Customer Service 420 Rue d'Estienne d'Orves 92705 COLOMBES Cedex, France Tel.: +33 (0) 149 008 080 www.arkema.com/en/markets-and-solutions/contact/

arkemaepoxides.com

Arkema Inc. Oxygénés & Derivatives Customer Service 900 First Avenue King of Prussia, PA 19406-1308 USA Tel.: +1 (800) 346-5757 Fax: +1 610-205-7634 Email: arkema.usph-hydrogen-peroxides-cs@arkema.com